

# Evaluating Nanogaps in Ag and Au Nanoparticle Clusters for SERS Application Using COMSOL Multiphysics®

R. Asapu<sup>1</sup>, R. Ciocarlan<sup>2</sup>, N. Claes<sup>3</sup>, N. Blommaerts<sup>1</sup>, S. Bals<sup>3</sup>, P. Cool<sup>2</sup>, S. Denys<sup>1</sup>, S.W. Verbruggen<sup>1</sup> and S. Lenaerts<sup>1</sup>

1. Department of Bioscience Engineering, DuEL Research Group, University of Antwerp, Antwerp, Belgium
2. Department of Chemistry, PLASMANT Research Group, University of Antwerp, Antwerp, Belgium
3. Department of Physics, EMAT Research Group, University of Antwerp, Antwerp, Belgium

**Introduction:** The hot spots generated in the nanogaps of plasmonic metal nanoparticles are the primary cause for surface enhanced Raman spectra (SERS). But, *matching the SERS laser wavelength and surface plasmon resonance of noble metal nanoparticles is crucial* to achieve higher enhancements. Near-field simulations using COMSOL provide crucial insights into the phenomenon underlying the electromagnetic enhancement of SERS.




Figure 1. Electromagnetic enhancement in SERS

**Computational Methods:** In wave optics module, Maxwell's electromagnetic wave equation is solved for scattered electric field,  $E_{sca}$ .

$$\nabla \times \left[ \frac{1}{\mu_r} (\nabla \times E_{sca}) \right] - K_0^2 \left[ \left( \epsilon_r - \frac{j\sigma}{\omega\epsilon_0} \right) E_{sca} \right] = 0$$

3D models of nanosphere and core-shell nanoparticles with required diameter were built with air as the surrounding medium enclosed within a PML. A mesh quality of ca. 0.7 was maintained and a plane wave polarized in the Z-direction, and propagating along the X-axis direction was solved in a wavelength domain study.




Figure 2. Model details with geometry and meshing

**Results:** Increase in nanogap results in the intensity loss of the hot spots, but gold nanoclusters perform better than silver nanoclusters as seen from enhancement factors,  $EF = |E/E_0|^4$  approx., and near-electric field maps.




Figure 3. Near-field maps and EF for Au/Ag dimers, Nanoparticle diameter ~ 20 nm




Figure 4. SERS EF for Ag nanoclusters (dia. ~ 20 nm)




Figure 5. SERS EF for Ag / Au nanoclusters (dia. ~ 20 nm)

Nanoparticle size dia.	EF <sub>532</sub> -Gold (Au)	EF <sub>532</sub> -Silver (Ag)
10 nm	1.4x10 <sup>5</sup>	3.0x10 <sup>4</sup>
20 nm	5.7x10 <sup>6</sup>	7.4x10 <sup>5</sup>
30 nm	3.6x10 <sup>7</sup>	8.1x10 <sup>6</sup>
40 nm	9.8x10 <sup>7</sup>	7.2x10 <sup>7</sup>
50 nm	2.0x10 <sup>8</sup>	6.1x10 <sup>8</sup>
60 nm	3.0x10 <sup>8</sup>	8.3x10 <sup>9</sup>
80 nm	4.1x10 <sup>8</sup>	1.1x10 <sup>11</sup>
100 nm	3.3x10 <sup>8</sup>	2.4x10 <sup>10</sup>

Table 1. Plasmonic metal nanoparticle size dependence on EF at a laser excitation wavelength of 532 nm

**Conclusions:** Nanogaps are crucial for the enhancement factor in SERS as the intense near-electric fields drop drastically within a few nanometers. Tuning the nanoparticle size and nanogap to match the surface plasmon resonance of the nanocluster system with the SERS laser wavelength will greatly enhance the Raman signal.

## References:

1. Stiles, P. L. & Van Duyne, R. P. et al. Surface-Enhanced Raman Spectroscopy. Annual. Rev. Anal. Chem. 1, 601–26 (2008).
2. Schlucker, S. Surface-Enhanced Raman Spectroscopy. Angew. Chem. Int. Ed. 53, 4756–95 (2014).